



Two-phase Flow Measurement System

This system detects individual bubble size and velocity using reflected light intensity technology that changes when a bubble penetrates through the tip of the wedge-shaped optical fiber.

Measures bubble size and velocity simultaneously

Applicable to nonconductive fluid

Highly accurate measurements derived from the correction calculation of the contact angle (F-TOP Sensor)

System Configuration

Đ

Fiber optics unit Highly accurate 4-tip optical fiber A/D converter Computer Measurement software



Application

- Nuclear reactor coolant
- Cavitation research

BubbleMaster

- Bubble column
- Gaseous diffusion in solution

Kanomax JAPAN, INC. Fluid Research Measurement Solutions Division 2-1 Shimizu Suita City Osaka 565-0805 JAPAN Phone 81-6-6877-8679 E-mail fluids@kanomax.co.jp http://www.kanomax.co.jp Information, data and specification in this brochure are subject to change without notice.



Specification

Measurement Method	Photoelectric detection
Feature	Simultaneous measurement of bubble velocity and diameter
Sensor	Wedge-shaped fiber
Measurable bubble size	1.0 mm ~
Max flow rate	10 m/s
Measurement Software	
Sampling system	Burst signal sampling
Real time monitor	Photoelectric conversion output signal
Data acquisition	Max. 100,000 (No. of bubbles)
Analysis display	Bubble velocity, bubble diameter, OK/NG
	Burst signal waveform
	Average, Standard deviation
Data table	Bubble velocity, Bubble size, OK/NG
Histogram chart	Bubble velocity, Bubble size





Block Diagram



S-TOP Sensor Principle

The signal change is detected when a bubble contacts and penetrates the sensor.







T-TOP Sensor Principle

Velocity is calculated based on the temporal differences of a bubble passing through two sensors.







F-TOP Sensor Principle

The F-TOP Sensor delivers a highly accurate measurement by having four integrated wedge-shaped optical fibers in one. Based on the phase difference and gradient of each optical fiber sensor detection signal, the bubble entry angle is calculated and corrected.



This product is developed with Regional Innovation Creation R&D Programs for FY 2008 supported by Kanto Bureau of Economy, Trade and Industry. Project leader: Prof. Takayuki Saito, Shizuoka University